



Cisco Nexus 5548UP

Switch Configuration Guide for EqualLogic SANs

Dell Storage Engineering
March 2014



SIFeedback@Dell.com

Revisions

Date	Description
February 2013	Initial release
October 2013	Updated for firmware 6.0(2)N1(2)
March 2014	Updated for firmware 7.0(0)N1(1) and added DCB with iSCSI TLV configuration.

© 2014 Dell Inc. All rights reserved. Reproduction of this material in any manner whatsoever without the express written permission of Dell Inc. is strictly forbidden. For more information, contact Dell.

Dell, the Dell logo, and the Dell badge, PowerConnect, EqualLogic, and Force10 are trademarks of Dell Inc. Cisco® is a registered trademark of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries.



Table of contents

Revisions.....	2
1 Introduction.....	5
1.1 Audience.....	5
1.2 Switch details.....	5
1.3 Cabling diagram.....	5
2 Dell recommended switch configuration.....	7
2.1 Hardware configuration.....	7
2.2 Delete startup configuration.....	7
2.3 Running the basic system configuration.....	7
2.4 Configure the vPC domain.....	9
2.5 Configure Port Channel.....	9
2.6 Enable link level flow control (802.3x).....	10
2.7 Configure portfast on edge ports.....	10
2.8 Enable VLAN.....	11
2.9 Enable switch ports.....	11
2.10 Configure the Nexus policy engine.....	11
2.10.1 Configure CoS for iSCSI.....	12
2.10.2 Define a QoS map for iSCSI.....	12
2.10.3 Define a QoS policy map for iSCSI.....	12
2.10.4 Define a Network QoS class map.....	12
2.10.5 Define a no-drop policy map and enable jumbo frames.....	12
2.10.6 Define a queuing class-map.....	13
2.10.7 Define a queuing policy-map.....	13
2.11 Apply the Nexus policies.....	13
2.12 Save configuration.....	13
2.13 Configure additional switch.....	13
3 Configure Data Center Bridging (DCB) (Optional).....	14
3.1 Configure the vPC domain.....	14
3.2 Configure Port Channel.....	14
3.3 Configure portfast on edge ports.....	15
3.3.1 Configure VLANs for iSCSI.....	15



3.4	Enable VLAN.....	16
3.5	Configure the Nexus policy engine	16
3.5.1	Define a QoS map for iSCSI	16
3.5.2	Define a QoS policy map for iSCSI	16
3.5.3	Define a queuing class-map	16
3.5.4	Define a Network QoS class map	16
3.5.5	Define a queuing policy-map	17
3.5.6	Define a no-drop policy map and enable jumbo frames	17
3.6	Apply the Nexus policies.....	17
3.7	Save configuration	18
3.8	Disabling DCB (optional).....	18
	Additional resources.....	19



1 Introduction

This document illustrates how to configure Cisco® Nexus 5548UP switches for use with EqualLogic™ PS Series storage using Dell™ best practices. The recommended configuration uses link aggregation groups (LAGs) and Virtual Port Channel (vPC) for inter-switch connections.

For more information on EqualLogic SAN design recommendations, see the EqualLogic Configuration Guide at: www.delltechcenter.com/page/equallogic+configuration+guide.

1.1 Audience

This switch configuration guide describes a verified configuration following Dell best practices for an EqualLogic iSCSI SAN and is intended for storage or network administrators and deployment personnel.

1.2 Switch details

The table below provides an overview of the switch configuration.

Table 1 Switch specifications

Cisco Nexus 5548UP	
Switch vendor	Cisco
Switch model	Nexus 5548UP
Switch firmware	7.0(0)N1(1)

Note: For proper functionality, the switch must be at the firmware version shown in the table above before proceeding with this configuration. Using previous firmware versions may have unpredictable results.

The latest firmware updates and documentation can be found at: www.cisco.com. This site requires a login.

1.3 Cabling diagram

The cabling diagram shown below represents the Dell recommend method for deploying your servers and EqualLogic arrays.






Figure 1 Cabling diagram



2 Dell recommended switch configuration

These steps show you how to configure two Cisco Nexus 5548UP switches with a vPC interconnect. The switches are interconnected using four of the 10Gb ports configured as the vPC link.

Note: The configuration steps in this section are only recommended when the switch is used as a dedicated SAN for iSCSI traffic (not shared with LAN traffic).

2.1 Hardware configuration

1. Power on both switches
2. Connect a serial cable to the management port.
3. Using Putty or another terminal utility, open a serial connection session to the switch.
4. Open your terminal emulator and configure it to use the serial port (usually COM1 but this may vary depending on your system). Configure serial communications for 9600,N,8,1 and no flow control.
5. Connect the cables between switch 1 and switch 2 as shown in Figure 1, for ports 1-4. This will be used as your vPC link.

2.2 Delete startup configuration

Note: This example assumes a switch at its default configuration settings. Using the “write erase” command will set the startup configuration file to its default settings. You should always backup your configuration settings prior to performing any configuration changes

```
switch>enable
```

```
switch#write erase
```

```
Warning: This command will erase the startup-configuration  
Do you wish to proceed anyway ? (y/n) [n] y
```

```
switch# reload
```

```
WARNING: this command will reboot the system  
Do you want to continue? (y/n) [n] y
```

Note: The switch will reboot.

2.3 Running the basic system configuration

The following steps use the setup utility to configure connectivity for basic management of the system.

After the switch fully reboots, the following prompts will appear:

```
Abort Power On Auto Provisioning and continue with normal setup ?(yes/no) [n]: y
```



---- System Admin Account Setup ----

Do you want to enforce secure password standard (yes/no): **yes**

Enter the password for "admin": **my password**

Confirm the password for "admin": **my password**

---- Basic System Configuration Dialog ----

This setup utility will guide you through the basic configuration of the system. Setup configures only enough connectivity for management of the system.

Please register Cisco Nexus 5000 Family devices promptly with your supplier. Failure to register may affect response times for initial service calls. Nexus devices must be registered to receive entitled support services.

Press Enter at anytime to skip a dialog. Use ctrl-c at anytime to skip the remaining dialogs.

Would you like to enter the basic configuration dialog (yes/no): **yes**

Create another login account (yes/no) [n]: **n**

Configure read-only SNMP community string (yes/no) [n]: **n**

Configure read-write SNMP community string (yes/no) [n]: **n**

Enter the switch name : **my switch name**

Continue with Out-of-band (mgmt0) management configuration? (yes/no) [y]: **y**

Mgmt0 IPv4 address : **my IP address**

Mgmt0 IPv4 netmask : **my netmask**

Configure the default gateway? (yes/no) [y]: **y**

IPv4 address of the default gateway : **my gateway**

Enable the telnet service? (yes/no) [n]: **y**

Enable the ssh service? (yes/no) [y]: **n**

Configure the ntp server? (yes/no) [n]: **n**

Enter basic FC configurations (yes/no) [n]: **n**

The following configuration will be applied:
switchname **my switch name**




```

interface mgmt0
ip address my ip address my netmask
no shutdown
exit
vrf context management
ip route 0.0.0.0/0 my gateway
exit
telnet server enable
no ssh server enable

Would you like to edit the configuration? (yes/no) [n]: n

Use this configuration and save it? (yes/no) [y]: y

[#####] 100%
Copy complete, now saving to disk (please wait)...

```

Log in with the credentials created in the previous steps.

Note: For Data Center Bridging (DCB) configuration, skip to Section 3.0.

2.4 Configure the vPC domain

```

switch# configure

switch(config)#feature lacp

switch(config)#feature vpc

switch(config)#vpc domain 1

switch(config-vpc-domain)#peer-keepalive destination peer IP address
-----:: Management VRF will be used as the default VRF ::-----

```

Note: For the *<peer IP address>*, use the management IP address of the partner switch.

```

switch(config-vpc-domain)#exit

```

2.5 Configure Port Channel

```

switch(config)# interface port-channel 1

switch(config-if)# switchport mode trunk

switch(config-if)# spanning-tree port type network

switch(config-if)# vpc peer-link
Please note that spanning tree port type is changed to "network" port type on

```



vPC peer-link. This will enable spanning tree Bridge Assurance on vPC peer-link provided the STP Bridge Assurance (which is enabled by default) is not disabled.

```
switch(config-if)# exit
```

```
switch(config)# interface ethernet 1/1-4
```

```
switch(config-if-range)# switchport mode trunk
```

```
switch(config-if-range)# channel-group 1 mode active
```

```
switch(config-if-range)# exit
```

```
switch(config)# interface port-channel 1
```

```
switch(config-if)#priority-flow-control mode off
```

```
switch(config-if)# flowcontrol send on
```

```
switch(config-if)# flowcontrol receive on
```

```
switch(config-if)# exit
```

2.6 Enable link level flow control (802.3x)

You must perform this step for each individual port that is connected to a storage controller or a host interface port, or you can specify a range of ports to configure.

```
switch(config)#interface ethernet 1/5-32
```

```
switch(config-if-range)#priority-flow-control mode off
```

```
switch(config-if-range)#flowcontrol send on
```

```
switch(config-if-range)#flowcontrol receive on
```

```
switch(config-if-range)#exit
```

2.7 Configure portfast on edge ports

```
switch(config)#interface ethernet 1/5-32
```

```
switch(config-if-range)#spanning-tree port type edge
```



Warning: edge port type (portfast) should only be enabled on ports connected to a single host. Connecting hubs, concentrators, switches, bridges, etc... to this interface when edge port type (portfast) is enabled, can cause temporary bridging loops. Use with CAUTION.

Edge Port Type (Portfast) will be configured in 28 interfaces due to the range command but will only have effect when the interfaces are in a non-trunking mode.

```
switch(config-if-range)#exit
```

2.8 Enable VLAN

The following example uses VLAN 101 and configures a range of ports. Any valid VLAN (between 2-4094) may be substituted.

```
switch(config)# vlan 101
```

```
switch(config-vlan)# exit
```

```
switch(config)# interface ethernet 1/5-32
```

Note: Switch ports 1-4 are part of port-channel 1 so are not included in the above range.

```
switch(config-if-range)# switchport access vlan 101
```

```
switch(config-if-range)# exit
```

2.9 Enable switch ports

The following example enables a range of ports. If preferred, you may enable individual ports as needed.

```
switch(config)# interface ethernet 1/1-32
```

```
switch(config-if-range)# shutdown
```

```
switch(config-if-range)# no shutdown
```

```
switch (config-if-range)# exit
```

2.10 Configure the Nexus policy engine

The following example configures iSCSI traffic for Class of Service (CoS) 4 and Quality of Service (QoS) group 3.



2.10.1 Configure CoS for iSCSI

Repeat this step for each individual interface connected to host and array controller ports, or specify a range of ports to configure.

```
switch(config)# interface ethernet 1/5-32  
switch(config-if-range)# untagged cos 4  
switch(config-if-range)# exit
```

2.10.2 Define a QoS map for iSCSI

```
switch(config)# class-map type qos class-iscsi  
switch(config-cmap-qos)# match cos 4  
switch(config-cmap-qos)# exit
```

2.10.3 Define a QoS policy map for iSCSI

```
switch(config)# policy-map type qos policy-qos  
switch(config-pmap-qos)# class type qos class-iscsi  
switch(config-pmap-c-qos)# set qos-group 3  
switch(config-pmap-c-qos)# exit  
switch(config-pmap-qos)# exit
```

2.10.4 Define a Network QoS class map

```
switch(config)# class-map type network-qos class-iscsi  
switch(config-cmap-nq)# match qos-group 3  
switch(config-cmap-nq)# exit
```

2.10.5 Define a no-drop policy map and enable jumbo frames

```
switch(config)# policy-map type network-qos policy-nq  
switch(config-pmap-nq)# class type network-qos class-iscsi  
switch(config-pmap-nq-c)# mtu 9216  
switch(config-pmap-nq-c)# pause no-drop  
switch(config-pmap-nq-c)# exit  
switch(config-pmap-nq)# exit
```



2.10.6 Define a queuing class-map

```
switch(config)# class-map type queuing class-iscsi  
  
switch(config-cmap-que)# match qos-group 3
```

2.10.7 Define a queuing policy-map

```
switch(config-cmap-que)# policy-map type queuing policy-queuing  
  
switch(config-pmap-que)# class type queuing class-default  
  
switch(config-pmap-c-que)# bandwidth percent 5  
  
switch(config-pmap-c-que)# class type queuing class-fcoe  
  
switch(config-pmap-c-que)# bandwidth percent 0  
  
switch(config-pmap-c-que)# class type queuing class-iscsi  
  
switch(config-pmap-c-que)# bandwidth percent 95  
  
switch(config-pmap-c-que)# exit  
  
switch(config-pmap-que)# exit
```

2.11 Apply the Nexus policies

```
switch(config)# system qos  
  
switch(config-sys-qos)# service-policy type qos input policy-qos  
  
switch(config-sys-qos)# service-policy type queuing output policy-queuing  
  
switch(config-sys-qos)# service-policy type queuing input policy-queuing  
  
switch(config-sys-qos)# service-policy type network-qos policy-nq  
  
switch(config-sys-qos)# exit  
  
switch(config)# exit
```

2.12 Save configuration

```
switch#copy running-config startup-config
```

2.13 Configure additional switch

Repeat the commands from Sections 2.1 through 2.13.12 to configure the second switch.



3 Configure Data Center Bridging (DCB) (Optional)

To enable DCB mode on the switch, use the following procedures:

Note: The following section assumes a new switch that has a default startup configuration file. Always backup the startup configuration file prior to making any configuration changes.

Note: This section enables Data Center Bridging for implementing a converged network (LAN and SAN traffic sharing the same switch fabric). Hosts connecting to EqualLogic iSCSI storage must have a supported Converged Network Adapter (CNA).

3.1 Configure the vPC domain

```
switch# configure

switch(config)#feature lacp

switch(config)#feature vpc

switch(config)#vpc domain 1

switch(config-vpc-domain)#peer-keepalive destination peer IP address
-----:: Management VRF will be used as the default VRF ::-----
```

Note: For the *<peer IP address>*, use the management IP address of the partner switch.

```
switch(config-vpc-domain)#exit
```

3.2 Configure Port Channel

```
switch(config)# interface port channel 1

switch(config-if)# switchport mode trunk

switch(config-if)# switchport trunk allowed vlan 100,200

switch(config-if)# spanning-tree port type network

switch(config-if)# vpc peer-link
Please note that spanning tree port type is changed to "network" port type on
vPC peer-link. This will enable spanning tree Bridge Assurance on vPC peer-link
provided the STP Bridge Assurance (which is enabled by default) is not disabled.

switch(config-if)# exit
```



```
switch(config)# interface ethernet 1/1-4

switch(config-if-range)# switchport mode trunk

switch(config-if-range)# switchport trunk allowed vlan 100,200

switch(config-if-range)# channel-group 1 mode active

switch(config-if-range)# exit
```

3.3 Configure portfast on edge ports

```
switch(config)#interface ethernet 1/5-32

switch(config-if-range)#spanning-tree port type edge
```

Warning: edge port type (portfast) should only be enabled on ports connected to a single host. Connecting hubs, concentrators, switches, bridges, etc... to this interface when edge port type (portfast) is enabled, can cause temporary bridging loops. Use with CAUTION.

Edge Port Type (Portfast) will be configured in 28 interfaces due to the range command but will only have effect when the interfaces are in a non-trunking mode.

```
switch(config-if-range)#exit
```

3.3.1 Configure VLANs for iSCSI

Repeat this step for each individual interface connected to host and array controller ports, or specify a range of ports to configure.

```
switch(config)# interface ethernet 1/5-32

switch(config-if-range)# switchport mode trunk

switch(config-if-range)# switchport trunk allowed vlan 100,200

switch(config-if-range)#exit
```



3.4 Enable VLAN

The following example uses VLAN 100 for SAN Storage and VLAN 200 for other traffic. Any valid VLAN (between 2-4094) may be substituted.

```
switch(config)# vlan 100,200  
  
switch(config-vlan)# exit
```

Note: Switch ports 1-4 are part of port-channel 1 so are not included in the above range.

3.5 Configure the Nexus policy engine

The following section configures iSCSI traffic for Class of Service (CoS) 4 and Quality of Service (QoS) group 4.

3.5.1 Define a QoS map for iSCSI

```
switch(config)# class-map type qos match-all class-iscsi  
  
switch(config-cmap-qos)# match protocol iscsi  
  
switch(config-cmap-qos)# match cos 4  
  
switch(config-cmap-qos)# exit
```

3.5.2 Define a QoS policy map for iSCSI

```
switch(config)# policy-map type qos iscsi-in-policy  
  
switch(config-pmap-qos)# class class-iscsi  
  
switch(config-pmap-c-qos)# set qos-group 4  
  
switch(config-pmap-c-qos)#exit  
  
switch((config-pmap-qos)# exit
```

3.5.3 Define a queuing class-map

```
switch(config)# class-map type queuing class-iscsi  
  
switch(config-cmap-que)# match qos-group 4  
  
switch(config-cmap-que)# exit
```

3.5.4 Define a Network QoS class map

```
switch(config)# class-map type network-qos class-iscsi
```




```
switch(config-cmap-nq) # match qos-group 4  
switch(config-cmap-nq) # exit
```

3.5.5 Define a queuing policy-map

```
Switch(config) # policy-map type queuing iscsi-in-policy  
  
switch(config-pmap-que) # class type queuing class-default  
  
switch(config-pmap-c-que) # bandwidth percent 5  
  
switch(config-pmap-c-que) # class type queuing class-fcoe  
  
switch(config-pmap-c-que) # bandwidth percent 0  
  
switch(config-pmap-c-que) # class type queuing class-iscsi  
  
switch(config-pmap-c-que) # bandwidth percent 95  
  
switch(config-pmap-c-que) # exit  
  
switch(config-pmap-que) # exit
```

3.5.6 Define a no-drop policy map and enable jumbo frames

```
switch(config) # policy-map type network-qos iscsi-nq-policy  
  
switch(config-pmap-nq) # class type network-qos class-iscsi  
  
switch(config-pmap-nq-c) # set cos 4  
  
switch(config-pmap-nq-c) # mtu 9216  
  
switch(config-pmap-nq-c) # pause no-drop  
  
switch(config-pmap-nq-c) # exit  
  
switch(config-pmap-nq) # exit
```

3.6 Apply the Nexus policies

```
switch(config) # system qos  
  
switch(config-sys-qos) # service-policy type qos input iscsi-in-policy  
  
switch(config-sys-qos) # service-policy type queuing input iscsi-in-policy  
  
switch(config-sys-qos) # service-policy type queuing output iscsi-in-policy  
  
switch(config-sys-qos) # service-policy type network-qos iscsi-nq-policy
```



```
switch(config-sys-qos) # exit
```

```
switch(config) # exit
```

3.7 Save configuration

```
switch#copy running-config startup-config
```

3.8 Disabling DCB (optional)

Note: With the current Cisco Nexus firmware, it is not possible to fully disable DCB functionality correctly. Using the configuration steps in Section 2 of this document results in a proper non-DCB environment. In addition, disabling LLDP support can effectively prevent the negotiation of DCB by preventing the transmission of DCBx frames. However, disabling LLDP may also reduce functionality necessary for other protocols. **Only disable LLDP if instructed by Dell support.** The following example disables LLDP support on ports 1 through 32.

```
switch#configure
```

```
switch(config)#interface ethernet 1/1-32
```

```
switch(config-if-range)# no lldp receive
```

```
switch(config-if-range)# no lldp transmit
```



Additional resources

[Support.dell.com](http://support.dell.com) is focused on meeting your needs with proven services and support.

[Support.cisco.com](http://support.cisco.com) for support and information regarding Cisco networking products.

DellTechCenter.com is an IT Community where you can connect with Dell Customers and Dell employees for the purpose of sharing knowledge, best practices, and information about Dell products and your installations.

Referenced or recommended Dell publications:

- Dell EqualLogic Configuration Guide:
<http://en.community.dell.com/techcenter/storage/w/wiki/equallogic-configuration-guide.aspx>
- Dell EqualLogic Compatibility Matrix:
<http://en.community.dell.com/techcenter/storage/w/wiki/2661.equallogic-compatibility-matrix.aspx>

For EqualLogic best practices white papers, reference architectures, and sizing guidelines for enterprise applications and SANs, refer to Storage Infrastructure and Solutions Team Publications at:

- <http://dell.to/sM4hJT>

